HOW TO: Install an easy-fit cover to a jockey seat



Shark P/N#:

ULTRA seat: FBXX0000 Easy-fit cover: FXXXAD04

HARDWARE SPECIFIC TO PROCESS:

- (4) M8 x 30MM BUTTON HEAD BOLTS
- (4) NYLOC NUTS
- (4) BLACK WASHERS
- (2) ZIP TIES

TOOLS REQUIRED:

- (1) 5MM HEX KEY
- (1) SCISSORS





A. Remove Existing Side Handles

Start by removing both of the side handles. Use a five-millimeter hex key and remove the 4 M8 x 30mm button head bolts from the inner side of the handles. When loosening, it is best to do this slowly and with a manual tool. Once the bolts are free, remove the handles from both sides. Make sure no bolts are left in the seat.

B. Placing the Cover

Starting with the pommel, slide the cover over firmly, ensuring the stitch lines of the cover sit securely in the creases of the seat. Then, take the top of the cover and place it over the top of the seat. Give the cover a pat down in the creases to ensure it is sitting correctly. Now, flip the seat onto its side and have one of the exposed seat corners facing away from you. Place your hands on either side of the stitch line of the cover and pull it over the corner of the seat with some force to slide it over. Make sure that the stitch line is centered over the tip of the seat corner. Once the cover is over, evenly spread the fabric surrounding the corner, removing and lines and wrinkles that may appear. Repeat this procedure for the other side of the seat, patting down all the creases to ensure it is sitting nicely.



HOW TO: Install an easy-fit cover to a jockey seat



Shark P/N#:

ULTRA seat: FBXX0000 Easy-fit cover: FXXXAD04

HARDWARE SPECIFIC TO PROCESS:

- (4) M8 x 30MM BUTTON HEAD BOLTS
- (4) NYLOC NUTS
- (4) BLACK WASHERS
- (2) ZIP TIES

TOOLS REQUIRED:

- (1) 5MM HEX KEY
- (1) SCISSORS





C. Reattaching Side Handles

To reattach the side handles, locate the pre-drilled holes in the cover. Take the bolts with black washers over them (that came from the side handles) and place them through the inside of the seat so the threads of the bolts poke outwards. Do this to all of the exposed holes. Take a side handle and slide it over the exposed threads. Take 2 nyloc nuts and place them in the outer holes of the handles ensuring the side with the blue ring is exposed. Fasten the bolts from inside the seat using a 5mm hex key. TIP: Place a finger over the nyloc nuts in the handle while slowly fastening to get the thread started. **Make sure to re-fasten slowly**. Repeat these steps for the remaining side handle.

D. Final Fastening (Zip Ties)

Finally, to secure the cover in place, flip the seat upside down. Find the two zip ties located under the pommel. Starting with the one that fastens the whole seat first, pull tightly at the wires on each side that connect to the zip tie without fastening it yet. This is to create tension and cut slack. Once the cover is snug around the seat, secure the zip tie. Do the same for the remaining zip tie at the front of the seat. Snip the excess material away from the zip-tie using scissors.